

INSTRUCTION MANUAL



ICEFREE3A and ICEFREE3V

Revision: 3/17



Copyright © 2015-2017
Campbell Scientific, Inc.

Limited Warranty

“Products manufactured by CSI are warranted by CSI to be free from defects in materials and workmanship under normal use and service for twelve months from the date of shipment unless otherwise specified in the corresponding product manual. (Product manuals are available for review online at www.campbellsci.com.) Products not manufactured by CSI, but that are resold by CSI, are warranted only to the limits extended by the original manufacturer. Batteries, fine-wire thermocouples, desiccant, and other consumables have no warranty. CSI’s obligation under this warranty is limited to repairing or replacing (at CSI’s option) defective Products, which shall be the sole and exclusive remedy under this warranty. The Customer assumes all costs of removing, reinstalling, and shipping defective Products to CSI. CSI will return such Products by surface carrier prepaid within the continental United States of America. To all other locations, CSI will return such Products best way CIP (port of entry) per Incoterms ® 2010. This warranty shall not apply to any Products which have been subjected to modification, misuse, neglect, improper service, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied. The warranty for installation services performed by CSI such as programming to customer specifications, electrical connections to Products manufactured by CSI, and Product specific training, is part of CSI’s product warranty. **CSI EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CSI hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the Products, whether express, implied or statutory, other than those expressly provided herein.”**

Assistance

Products may not be returned without prior authorization. The following contact information is for US and international customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit www.campbellsci.com to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 227-9000. Please write the issued RMA number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

CAMPBELL SCIENTIFIC, INC.

RMA# _____
815 West 1800 North
Logan, Utah 84321-1784

For all returns, the customer must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our website at www.campbellsci.com/repair. A completed form must be either emailed to repair@campbellsci.com or faxed to (435) 227-9106. Campbell Scientific is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer's expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Safety

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.com or by telephoning (435) 227-9000 (USA). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Introduction	1
2. Precautions	1
3. Initial Inspection	1
4. Overview	1
5. Specifications	2
5.1 Wind Direction (ICEFREE3V)	2
5.2 Wind Speed (ICEFREE3A)	2
6. Installation	3
6.1 Siting	3
6.2 Wiring	3
6.2.1 ICEFREE3A Anemometer Wiring	3
6.2.2 ICEFREE3V Vane Wiring	4
6.3 Datalogger Programming	5
6.3.1 ICEFREE3A Wind Speed	5
6.3.2 ICEFREE3V Wind Direction	5
7. Troubleshooting	6
7.1 Wind Direction	6
7.2 Wind Speed	6
8. References	7

Appendices

A. Example Program	A-1
B. Wind Direction Sensor Orientation	B-1
B.1 Determining True North and Sensor Orientation	B-1

Figures

B-1	Magnetic declination for the contiguous United States (2004)	B-2
B-2.	Declination angles east of True North are subtracted from 0 to get True North	B-3
B-3.	Declination angles west of True North are added to 0 to get True North	B-3

Tables

6-1.	ICEFREE3A Datalogger Connections (grey cable)	4
6-2.	ICEFREE3A Heater-to-24 V Power Supply Connections (red cable).....	4
6-3.	ICEFREE3V Datalogger Connections (grey cable)	4
6-4.	ICEFREE3V Heater-to-24 V Power Supply Connections (red cable).....	4
6-5.	Wind Speed Multiplier for m/s*	5
6-6.	Parameters for BRHalf Instruction	6

CRBasic Example

A-1.	CR1000 Program Measuring the ICEFREE3A and ICEFREE3V ..	A-1
------	---	-----

ICEFREE3A and ICEFREE3V

1. Introduction

The ICEFREE3 anemometer and vane are electrically-heated wind sensors for ice-prone sites. They are manufactured by NRG. Campbell Scientific uses the model number ICEFREE3A for the anemometer, and ICEFREE3V for the vane.

These sensors are reliable in heavy and light winds. They can accurately measure winds in excess of 90 m s^{-1} (200 mph), yet their relatively low moment of inertia permits them to respond rapidly to gusts and lulls. Please note that these sensors have a high-power draw and should be used in applications where ac power is available.

2. Precautions

- READ AND UNDERSTAND the *Safety* section at the front of this manual.
- Although the ICEFREE3A and ICEFREE3V are rugged, they should be handled as precision scientific instruments.
- A 15 A slow-blow fuse should be placed in line with the heater.
- Do not apply greater than 30 V to the outputs at any time.
- When wiring the sensor, first connect the ground terminals and then connect the signal wires.

3. Initial Inspection

- Upon receipt of the ICEFREE3A and ICEFREE3V, inspect the packaging and contents for damage. File damage claims with the shipping company.

4. Overview

The ICEFREE3V senses wind direction with a potentiometer. With the precision excitation voltage from the datalogger applied to the potentiometer element, the output signal is an analog voltage that is directly proportional to the azimuth of the wind direction.

The ICEFREE3A monitors wind speed using a three-cup anemometer. Rotation of the cup wheel produces a sine-wave that is directly proportional to wind speed. The frequency of the sine wave is measured by the datalogger pulse count channel, then converted to engineering units (mph, m s^{-1} , knots).

5. Specifications

Features:

- Made of cast aluminum with black anodized finish and heat-resistant paint
- Efficiently transfers heat from encapsulated, self-regulating heaters
- Easily mounts to a 27 mm (1.05 in) diameter mounting pipe
- Powered by 24 V ac/dc
- Compatible with Campbell Scientific CRBasic dataloggers: CR200(X) series, CR300 series, CR6 series, CR800 series, CR1000, and CR3000

Mounting: Mounts to a pipe with a 27 mm (1.05 in) outer diameter

5.1 Wind Direction (ICEFREE3V)

Range Mechanical:	360° Electrical: 352° (8° open)
Potentiometer Linearity:	within 1%
Potentiometer Resistance:	0 to 10 kΩ
Operating Temperature Range:	-40 to 80 °C
Operating Humidity Range:	0 to 100% RH
Overall Assembly Height:	23.9 cm (9.41 in)
Body Diameter:	7.0 cm (2.75 in)
Swept Diameter:	21.2 cm (8.38 in)
Center-to-Tail Radius:	10.6 cm (4.19 in)
Cable Lengths (signal and power):	8 m (26 ft)
Weight:	1.58 kg (2 lb)
Supply Voltage:	24 V ac/dc
Supply Current Inrush:	8 A maximum
Supply Current Steady State:	1 A at 20 °C, 4 A under maximum thermal load (head frozen in clear ice then powered on)

5.2 Wind Speed (ICEFREE3A)

Range: 0 to 90 m s⁻¹ (0 to 200 mph)

Sensor to Sensor Variation:	99.7% of sensors fall within 4.3% of stated transfer function (based on over 800 samples)
Distance Constant (63% recovery):	7.6 m (25 ft)
Sensor Output Signal Range:	0 Hz to 155 Hz
Operating Temperature Range:	−40 to 60 °C
Operating Humidity Range:	0 to 100% RH
Overall Assembly Height:	22.4 cm (8.82 in)
Body Diameter:	7.0 cm (2.75 in)
Swept Diameter of Rotor:	12.7 cm (5 in)
Cable Lengths (signal and power):	8 m (26 ft)
Weight:	1.45 kg (3.2 lb)
Supply Voltage:	24 V ac/dc
Supply Current Inrush:	8 A maximum
Supply Current Steady State:	1 A at 20 °C, 4 A under maximum thermal load (head frozen in clear ice then powered on)

6. Installation

6.1 Siting

Locate wind sensors away from obstructions such as trees and buildings. As a general rule, there should be a horizontal distance of at least ten times the height of the obstruction between the wind set and the obstruction. If it is necessary to mount the sensors on the roof of a building, the height of the sensors, above the roof, should be at least 1.5 times the height of the building. See Section 8, *References* (p. 7), for a list of references that discuss siting wind speed and direction sensors.

The ICEFREE3V vane needs to be oriented to true north (Appendix B, *Wind Direction Sensor Orientation* (p. B-1)).

6.2 Wiring

6.2.1 ICEFREE3A Anemometer Wiring

The grey cable connects the anemometer to the datalogger (TABLE 6-1), and the red cable connects the anemometer's heater to a 24 V power supply (TABLE 6-2).

TABLE 6-1. ICEFREE3A Datalogger Connections (grey cable)		
Wire Color	Wire Function	Datalogger Connection Terminal
Clear	Signal	U configured for pulse input ¹ , P (pulse input), or P_SW (pulse, switch closure input)
Black	Signal Reference	\perp
Shield	Shield	AG or \perp (analog ground)

¹U channels are automatically configured by the measurement instruction.

TABLE 6-2. ICEFREE3A Heater-to-24 V Power Supply Connections (red cable)		
Color	Description	24 V Heater
Black	Voltage	24 V
White	Ground	G

6.2.2 ICEFREE3V Vane Wiring

The grey cable connects the vane to the datalogger (TABLE 6-3), and the red cable connects the vane's heater to a 24 V power supply (TABLE 6-4).

TABLE 6-3. ICEFREE3V Datalogger Connections (grey cable)		
Wire Color	Wire Function	Datalogger Connection Terminal
Red	Voltage excitation input	U configured for voltage excitation ¹ , EX, VX (voltage excitation)
White	Analog voltage output	U configured for single-ended analog input ¹ , SE (single-ended, analog input)
Black	Reference	AG or \perp (analog ground)
Shield	Shield	AG or \perp (analog ground)

¹U channels are automatically configured by the measurement instruction.

TABLE 6-4. ICEFREE3V Heater-to-24 V Power Supply Connections (red cable)		
Color	Description	24 V Heater
Black	Voltage	24 V
White	Ground	G

6.3 Datalogger Programming

6.3.1 ICEFREE3A Wind Speed

Wind speed is measured with the **PulseCount()** instruction, using the low-level AC configuration and set to output frequency in hertz. The **PulseCount()** has the following form:

PulseCount(*Dest, Reps, PChan, PConfig, POption, Mult, Offset*)

Where,

- *PConfig*: Enter 1 for Low level AC (pulse channels only)
- *POption*: Enter 1 for output in hertz

The following expression for wind speed (U) is used to determine the multiplier and offset:

$$U = MX + B$$

where

M = multiplier

X = number of pulses per second (hertz)

B = offset

TABLE 6-5 lists the multipliers (M) and offsets (Off) to obtain meters/second when the **PulseCount()** instruction is configured to output the result in hertz.

TABLE 6-5. Wind Speed Multiplier for m/s*	
Multiplier	0.572
Offset	1
*When configured to output counts, the multiplier above is divided by the execution interval in seconds.	

6.3.2 ICEFREE3V Wind Direction

Except for the CR200(X) series, the **BRHalf()** instruction measures wind direction. The **BRHalf()** instruction has the following form:

BrHalf(*Dest, Reps, Range, SEChan, ExChan, MeasPEX, ExmV, RevEx, SettlingTime, Integ or f_{NI}, Mult, Offset*)

TABLE 6-6 provides the excitation voltages, range codes, multipliers, and offsets for the **BRHalf()** instruction. The multiplier value converts the sensor's millivolt output to degrees.

TABLE 6-6. Parameters for BRHalf Instruction

	CR800 CR850 CR1000	CR6 CR3000	CR300
Measurement Range	2500 mV	5000 mV	2500 mV
Integration or f_{N1}	60 Hz, reverse excitation	60 Hz, reverse excitation	60 Hz
Excitation Voltage	2500 mV	2500 mV	2500 mV
Multiplier	360	360	360
Offset	0	0	0

For the CR200(X)-series dataloggers, the **ExDeISE()** measures wind direction. The **ExDeISE()** has the following form:

ExDeISE(Dest,Reps, SEChan, ExChan, ExmV, Delay, Mult, Offset)

Choose 2500 mV for the excitation millivolts and enter 0.144 for the multiplier and 0.0 for the offset.

7. Troubleshooting

7.1 Wind Direction

Symptom: NAN, -9999, or no change in direction

1. Check that the sensor is wired to the excitation and single-ended channel specified by the measurement instruction.
2. Verify that the excitation voltage and range code are correct for the datalogger type.

Symptom: Incorrect wind direction

1. Verify that the excitation voltage, range code, multiplier and offset parameters are correct for the datalogger type.
2. Check orientation of sensor as described in Section 6, *Installation* (p. 3).

7.2 Wind Speed

Symptom: No wind speed

1. Check that the sensor is wired to the pulse channel specified by the pulse count instruction.
2. Verify that the configuration code (low level ac, hertz), and multiplier and offset parameters for the pulse count instruction are correct for the datalogger type.

8. References

The following references give detailed information on siting wind speed and wind direction sensors.

EPA, 1989: *Quality Assurance Handbook for Air Pollution Measurements System*, Office of Research and Development, Research Triangle Park, NC, 27711.

EPA, 1987: *On-Site Meteorological Program Guidance for Regulatory Modeling Applications*, EPA-450/4-87-013, Office of Air Quality Planning and Standards, Research Triangle Park, NC 27711.

The State Climatologist, 1985: *Publication of the American Association of State Climatologists: Height and Exposure Standards*, for Sensors on Automated Weather Stations, vol. 9, No. 4.

WMO, 1983: *Guide to Meteorological Instruments and Methods of Observation*, World Meteorological Organization, No. 8, 5th edition, Geneva, Switzerland.

Appendix A. Example Program

The following is a CR1000 program that measures the ICEFREE3A and ICEFREE3V.

CRBasic Example A-1. CR1000 Program Measuring the ICEFREE3A and ICEFREE3V

```
'CR1000

'Declare Variables and Units
Public Batt_Volt
Public Wind_Speed
Public Wind_Dir

Units Batt_Volt=Volts
Units Wind_Speed =meters/second

'Define Data Tables
DataTable(Table1,True,-1)
DataInterval(0,10,Min,10)
Average(1,Wind_Speed,FP2,False)
WindVector(1,Wind_Speed,Wind_Dir,FP2,False,0,0,4)
FieldNames("Wind_Dir_D1_WVT,Wind_Dir_SD1,WVT")
EndTable

'Main Program
BeginProg
Scan(5,Sec,1,0)
'Default Datalogger Battery Voltage measurement Batt_Volt:
Battery(Batt_Volt)

'Measure Wind Speed with ICEFREE3 Anemometer in m/s:
PulseCount(Wind_Speed,1,1,1,1,0.572,1)
If Wind_Speed <= 1 Then Wind_Speed = 0

'ICEFREE3V Wind Direction Sensor measurement Wind_Dir
BrHalf(Wind_Dir,1,mV2500,1,Vx1,1,2500,True,0,_60Hz,360,0)

'Call Data Tables and Store Data
CallTable(Table1)
NextScan
EndProg
```


Appendix B. Wind Direction Sensor Orientation

B.1 Determining True North and Sensor Orientation


Orientation of the wind direction sensor is done after the datalogger has been programmed, and the location of True North has been determined. True North is usually found by reading a magnetic compass and applying the correction for magnetic declination; where magnetic declination is the number of degrees between True North and Magnetic North. The preferred method to obtain the magnetic declination for a specific site is to use a computer service offered by NOAA at www.ngdc.noaa.gov/geomag. Magnetic declination can also be obtained from a map or local airport. A general map showing magnetic declination for the contiguous United States is shown in FIGURE B-1.

Declination angles east of True North are considered negative, and are subtracted from 360 degrees to get True North as shown FIGURE B-2 (0° and 360° are the same point on a compass). For example, the declination for Logan, Utah is 14° East. True North is $360^\circ - 14^\circ$, or 346° as read on a compass. Declination angles west of True North are considered positive, and are added to 0 degrees to get True North as shown in FIGURE B-3.

Orientation is most easily done with two people, one to aim and adjust the sensor, while the other observes the wind direction displayed by the datalogger.

1. Establish a reference point on the horizon for True North.
2. Sighting down the instrument center line, aim the nose cone, or counterweight at True North. Display the input location or variable for wind direction using a hand-held keyboard display, PC, or laptop.
3. Loosen the hardware that secures the base of the sensor to the crossarm. While holding the vane position, slowly rotate the sensor base until the datalogger indicates 0 degrees. Tighten the mounting hardware.

Magnetic Declination for the U.S. 2004



Mercator Projection

Contours of Declination of the Earth's magnetic field. Contours are expressed in degrees. Contour Interval: 1 Degree (Positive declinations in blue, negative in red)

Produced by NOAA's National Geophysical Data Center (NGDC), Boulder, Colorado

<http://www.ngdc.noaa.gov>

Based on the International Geomagnetic Reference Field (IGRF), Epoch 2000 updated to December 31, 2004

The IGRF is developed by the International Association of Geomagnetism and Aeronomy (IAGA), Division V

FIGURE B-1. Magnetic declination for the contiguous United States (2004)




FIGURE B-2. Declination angles east of True North are subtracted from 0 to get True North




FIGURE B-3. Declination angles west of True North are added to 0 to get True North

Campbell Scientific Companies

Campbell Scientific, Inc.

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Canada Corp.

14532 – 131 Avenue NW
Edmonton AB T5L 4X4
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Africa Pty. Ltd.

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.campbellsci.co.za • cleroux@csafrica.co.za

Campbell Scientific Centro Caribe S.A.

300 N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Southeast Asia Co., Ltd.

877/22 Nirvana@Work, Rama 9 Road
Suan Luang Subdistrict, Suan Luang District
Bangkok 10250
THAILAND

www.campbellsci.asia • info@campbellsci.asia

Campbell Scientific Ltd.

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Australia Pty. Ltd.

PO Box 8108
Garbutt Post Shop QLD 4814
AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific Ltd.

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific (Beijing) Co., Ltd.

8B16, Floor 8 Tower B, Hanwei Plaza
7 Guanghua Road
Chaoyang, Beijing 100004
P.R. CHINA

www.campbellsci.com • info@campbellsci.com.cn

Campbell Scientific Ltd.

Fahrenheitstraße 13
28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Campbell Scientific do Brasil Ltda.

Rua Apinagés, nbr. 2018 – Perdizes
CEP: 01258-00 – São Paulo – SP
BRASIL

www.campbellsci.com.br • vendas@campbellsci.com.br

Campbell Scientific Spain, S. L.

Avda. Pompeu Fabra 7-9, local 1
08024 Barcelona
SPAIN

www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.