

# APPLICATION NOTE



## *Weatherproofing Exterior Antenna Connections*



2/15



# Weatherproofing Exterior Antenna Connections

---

Wireless data-acquisition systems often include connections to cables, antennas, and surge protectors that are exposed to the natural environment. Following is an introduction to a technique designed to protect connections from water intrusion.

## What you will need:

- Roll of self-vulcanizing tape (cold shrink tape), 1 inch x 10 feet, Campbell Scientific pn 21212



- Scissors or tool for cutting the tape
- Cleaning supplies to clean the surge protector and connections
- Surge protection kit and antenna cables. An example kit is shown in the following figure. It is used in the following procedure.



## Procedure:

1. Inspect connection components. If connectors are contaminated with dust, oil, corrosion, etc, thoroughly clean the connections, being careful not to introduce any liquid into cable ends. Consider replacing connectors that have significant corrosion or cables that may have

become water or oil soaked. Corrosion and liquids will attenuate RF signals. Clean the body of the surge protector.

2. Connect the grounding wire to the case of the surge protector.



3. Complete the cable connections.



4. Wrap tape on individual connections.
  - Wrap tape in the direction of the threads. This tends to tighten the connection.
  - Apply tension while wrapping to make a good seal between tape and connectors and between tape layers.



5. Finish wrapping the connection.



6. Wrap the second connection in like manner.



7. Wrap both connections a second time, contiguous with the surge protector, from end to end. Extend the ground wire from the wrapping parallel to an antenna cable.



8. Secure the assembly, perhaps to the mast that supports the antenna. UV resistant cable ties are versatile fasteners. Point down the end from which the ground wire emerges to minimize the chance of moisture entry.









## Campbell Scientific Companies

---

**Campbell Scientific, Inc. (CSI)**

815 West 1800 North  
Logan, Utah 84321  
UNITED STATES

[www.campbellsci.com](http://www.campbellsci.com) • [info@campbellsci.com](mailto:info@campbellsci.com)

**Campbell Scientific Africa Pty. Ltd. (CSAf)**

PO Box 2450  
Somerset West 7129  
SOUTH AFRICA

[www.csafrica.co.za](http://www.csafrica.co.za) • [cleroux@csafrica.co.za](mailto:cleroux@csafrica.co.za)

**Campbell Scientific Australia Pty. Ltd. (CSA)**

PO Box 8108  
Garbutt Post Shop QLD 4814  
AUSTRALIA

[www.campbellsci.com.au](http://www.campbellsci.com.au) • [info@campbellsci.com.au](mailto:info@campbellsci.com.au)

**Campbell Scientific (Beijing) Co., Ltd.**

8B16, Floor 8 Tower B, Hanwei Plaza  
7 Guanghua Road  
Chaoyang, Beijing 100004  
P.R. CHINA

[www.campbellsci.com](http://www.campbellsci.com) • [info@campbellsci.com.cn](mailto:info@campbellsci.com.cn)

**Campbell Scientific do Brasil Ltda. (CSB)**

Rua Apinagés, nbr. 2018 — Perdizes  
CEP: 01258-00 — São Paulo — SP  
BRASIL

[www.campbellsci.com.br](http://www.campbellsci.com.br) • [vendas@campbellsci.com.br](mailto:vendas@campbellsci.com.br)

**Campbell Scientific Canada Corp. (CSC)**

14532 – 131 Avenue NW  
Edmonton AB T5L 4X4  
CANADA

[www.campbellsci.ca](http://www.campbellsci.ca) • [dataloggers@campbellsci.ca](mailto:dataloggers@campbellsci.ca)

**Campbell Scientific Centro Caribe S.A. (CSCC)**

300 N Cementerio, Edificio Breller  
Santo Domingo, Heredia 40305  
COSTA RICA

[www.campbellsci.cc](http://www.campbellsci.cc) • [info@campbellsci.cc](mailto:info@campbellsci.cc)

**Campbell Scientific Ltd. (CSL)**

Campbell Park  
80 Hathern Road  
Shepshed, Loughborough LE12 9GX  
UNITED KINGDOM

[www.campbellsci.co.uk](http://www.campbellsci.co.uk) • [sales@campbellsci.co.uk](mailto:sales@campbellsci.co.uk)

**Campbell Scientific Ltd. (CSL France)**

3 Avenue de la Division Leclerc  
92160 ANTONY  
FRANCE

[www.campbellsci.fr](http://www.campbellsci.fr) • [info@campbellsci.fr](mailto:info@campbellsci.fr)

**Campbell Scientific Ltd. (CSL Germany)**

Fahrenheitstraße 13  
28359 Bremen  
GERMANY

[www.campbellsci.de](http://www.campbellsci.de) • [info@campbellsci.de](mailto:info@campbellsci.de)

**Campbell Scientific Spain, S. L. (CSL Spain)**

Avda. Pompeu Fabra 7-9, local 1  
08024 Barcelona  
SPAIN

[www.campbellsci.es](http://www.campbellsci.es) • [info@campbellsci.es](mailto:info@campbellsci.es)

Please visit [www.campbellsci.com](http://www.campbellsci.com) to obtain contact information for your local US or international representative.