

INSTRUCTION MANUAL



SW12V 12 V Power Switch Assembly

12/15



Copyright © 2015
Campbell Scientific, Inc.

Limited Warranty

“Products manufactured by CSI are warranted by CSI to be free from defects in materials and workmanship under normal use and service for twelve months from the date of shipment unless otherwise specified in the corresponding product manual. (Product manuals are available for review online at www.campbellsci.com.) Products not manufactured by CSI, but that are resold by CSI, are warranted only to the limits extended by the original manufacturer. Batteries, fine-wire thermocouples, desiccant, and other consumables have no warranty. CSI’s obligation under this warranty is limited to repairing or replacing (at CSI’s option) defective Products, which shall be the sole and exclusive remedy under this warranty. The Customer assumes all costs of removing, reinstalling, and shipping defective Products to CSI. CSI will return such Products by surface carrier prepaid within the continental United States of America. To all other locations, CSI will return such Products best way CIP (port of entry) per Incoterms ® 2010. This warranty shall not apply to any Products which have been subjected to modification, misuse, neglect, improper service, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied. The warranty for installation services performed by CSI such as programming to customer specifications, electrical connections to Products manufactured by CSI, and Product specific training, is part of CSI’s product warranty. **CSI EXPRESSLY DISCLAIMS AND EXCLUDES ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CSI hereby disclaims, to the fullest extent allowed by applicable law, any and all warranties and conditions with respect to the Products, whether express, implied or statutory, other than those expressly provided herein.”**

Assistance

Products may not be returned without prior authorization. The following contact information is for US and international customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit www.campbellsci.com to determine which Campbell Scientific company serves your country.

To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 227-9000. After an application engineer determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. Campbell Scientific's shipping address is:

CAMPBELL SCIENTIFIC, INC.

RMA# _____
815 West 1800 North
Logan, Utah 84321-1784

For all returns, the customer must fill out a "Statement of Product Cleanliness and Decontamination" form and comply with the requirements specified in it. The form is available from our website at www.campbellsci.com/repair. A completed form must be either emailed to repair@campbellsci.com or faxed to (435) 227-9106. Campbell Scientific is unable to process any returns until we receive this form. If the form is not received within three days of product receipt or is incomplete, the product will be returned to the customer at the customer's expense. Campbell Scientific reserves the right to refuse service on products that were exposed to contaminants that may cause health or safety concerns for our employees.

Safety

DANGER — MANY HAZARDS ARE ASSOCIATED WITH INSTALLING, USING, MAINTAINING, AND WORKING ON OR AROUND TRIPODS, TOWERS, AND ANY ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC. FAILURE TO PROPERLY AND COMPLETELY ASSEMBLE, INSTALL, OPERATE, USE, AND MAINTAIN TRIPODS, TOWERS, AND ATTACHMENTS, AND FAILURE TO HEED WARNINGS, INCREASES THE RISK OF DEATH, ACCIDENT, SERIOUS INJURY, PROPERTY DAMAGE, AND PRODUCT FAILURE. TAKE ALL REASONABLE PRECAUTIONS TO AVOID THESE HAZARDS. CHECK WITH YOUR ORGANIZATION'S SAFETY COORDINATOR (OR POLICY) FOR PROCEDURES AND REQUIRED PROTECTIVE EQUIPMENT PRIOR TO PERFORMING ANY WORK.

Use tripods, towers, and attachments to tripods and towers only for purposes for which they are designed. Do not exceed design limits. Be familiar and comply with all instructions provided in product manuals. Manuals are available at www.campbellsci.com or by telephoning (435) 227-9000 (USA). You are responsible for conformance with governing codes and regulations, including safety regulations, and the integrity and location of structures or land to which towers, tripods, and any attachments are attached. Installation sites should be evaluated and approved by a qualified engineer. If questions or concerns arise regarding installation, use, or maintenance of tripods, towers, attachments, or electrical connections, consult with a licensed and qualified engineer or electrician.

General

- Prior to performing site or installation work, obtain required approvals and permits. Comply with all governing structure-height regulations, such as those of the FAA in the USA.
- Use only qualified personnel for installation, use, and maintenance of tripods and towers, and any attachments to tripods and towers. The use of licensed and qualified contractors is highly recommended.
- Read all applicable instructions carefully and understand procedures thoroughly before beginning work.
- Wear a **hardhat** and **eye protection**, and take **other appropriate safety precautions** while working on or around tripods and towers.
- **Do not climb** tripods or towers at any time, and prohibit climbing by other persons. Take reasonable precautions to secure tripod and tower sites from trespassers.
- Use only manufacturer recommended parts, materials, and tools.

Utility and Electrical

- **You can be killed** or sustain serious bodily injury if the tripod, tower, or attachments you are installing, constructing, using, or maintaining, or a tool, stake, or anchor, come in **contact with overhead or underground utility lines**.
- Maintain a distance of at least one-and-one-half times structure height, 20 feet, or the distance required by applicable law, **whichever is greater**, between overhead utility lines and the structure (tripod, tower, attachments, or tools).
- Prior to performing site or installation work, inform all utility companies and have all underground utilities marked.
- Comply with all electrical codes. Electrical equipment and related grounding devices should be installed by a licensed and qualified electrician.

Elevated Work and Weather

- Exercise extreme caution when performing elevated work.
- Use appropriate equipment and safety practices.
- During installation and maintenance, keep tower and tripod sites clear of un-trained or non-essential personnel. Take precautions to prevent elevated tools and objects from dropping.
- Do not perform any work in inclement weather, including wind, rain, snow, lightning, etc.

Maintenance

- Periodically (at least yearly) check for wear and damage, including corrosion, stress cracks, frayed cables, loose cable clamps, cable tightness, etc. and take necessary corrective actions.
- Periodically (at least yearly) check electrical ground connections.

WHILE EVERY ATTEMPT IS MADE TO EMBODY THE HIGHEST DEGREE OF SAFETY IN ALL CAMPBELL SCIENTIFIC PRODUCTS, THE CUSTOMER ASSUMES ALL RISK FROM ANY INJURY RESULTING FROM IMPROPER INSTALLATION, USE, OR MAINTENANCE OF TRIPODS, TOWERS, OR ATTACHMENTS TO TRIPODS AND TOWERS SUCH AS SENSORS, CROSSARMS, ENCLOSURES, ANTENNAS, ETC.

Table of Contents

PDF viewers: These page numbers refer to the printed version of this document. Use the PDF reader bookmarks tab for links to specific sections.

1. Introduction	1
2. Precautions	1
3. Initial Inspection.....	1
4. Specifications.....	1
5. Installation.....	1
5.1 Wiring	1
5.2 Datalogger Programming	2
5.2.1 Example Programs	2
5.2.1.1 CR1000 Program.....	2
5.2.1.2 CR10X Program.....	3

Table

5-1. SW12V Connections.....	1
-----------------------------	---

SW12V 12 V Power Switch Assembly

1. Introduction

The SW12V power switch allows a datalogger to supply power to a sensor only during measurement, thereby reducing current drain. The SW12V consists of a cable that connects to the datalogger, and a terminal block for connecting the external device.

The SW12V provides similar functionality as a datalogger's switched 12 V terminal. For newer dataloggers, the SW12V is used when datalogger's switched 12 V terminals are not available. It is also used with older dataloggers (for example, CR510, 21X, CR7) that do not have a switched 12 V terminal.

2. Precautions

- READ AND UNDERSTAND the [Safety](#) section at the front of this manual.

3. Initial Inspection

- Upon receipt of the SW12V, inspect the packaging and contents for damage. File damage claims with the shipping company.

4. Specifications

Features:

- Compatible with all Campbell Scientific dataloggers

Current ratings: 0.9 A @ 20 °C
0.65 A @ 50 °C
0.36 A @ 85 °C

Cable Length: 17.7 cm (18 in)

Control Line Voltage Range: 4 to 16 Vdc

5. Installation

5.1 Wiring

TABLE 5-1. SW12V Connections

Sensor	SW12V		Datalogger
Wire Description	Terminal	Wire	Terminal
Power	SW12V	Red	12V
Power Ground	GND	Black	G or \perp
		Green	Control Port

5.2 Datalogger Programming

CRBasic dataloggers use the **PortSet()** instruction to switch the power on and off. The **PortSet()** has the following form:

```
PortSet(Port, State)
```

Where,

Port: the control port used

State: nonzero value switches the power on and 0 switches the power off

NOTE

CRBasic programs need to use the sequential mode to ensure that 12 V will be turned on prior to the measurement.

Edlog dataloggers use the **Do (P86)** instruction to switch the power on and off.

Use code 4X in parameter 1, where X is the number of the control port used to switch the power on. Use code 5X to switch the power off.

5.2.1 Example Programs

5.2.1.1 CR1000 Program

The following CR1000 program uses control port 1 to switch the power on the SW12V on before measuring an HMP155A Temperature and Relative Humidity Sensor and then switches the power off after making the measurement.

```
SequentialMode
'Declare Variables and Units
Public Batt_Volt
Public AirTC
Public RH

Units Batt_Volt=Volts
Units AirTC=Deg C
Units RH=%

'Define Data Tables
DataTable(Temp_RH,True,-1)
  DataInterval(0,60,Min,0)
  Average(1,AirTC,IEEE4,0)
  Sample(1,RH,IEEE4)
EndTable

'Main Program
BeginProg
  Scan(5,Sec,1,0)
  'Default Datalogger Battery Voltage measurement Batt_Volt:
  Battery(Batt_Volt)
  'HMP155A measurements AirTC and RH:
  PortSet(1,1)
  Delay(0,2,Sec)
  VoltSE(AirTC,1,mV2500,2,0,0,_60Hz, .14,-80)
  VoltSE(RH,1,mV2500,1,0,0,_60Hz,0.1,0)
  PortSet(1,0)
  If RH>100 And RH<108 Then RH=100
  'Call Data Tables and Store Data
```

```

CallTable(Temp_RH)
NextScan
EndProg

```

5.2.1.2 CR10X Program

The following CR10X program uses the SW12V to switch the power on before measuring an HMP155A Temperature and Relative Humidity Sensor and then switches the power off making the measurement.

```

;Turn the HMP155A on.
;
01: Do (P86)
  1: 41      Set Port 1 High      ;Green wire (C1) if using SW12V device
                                   ;For CR23X use 49 for SW12V internal
                                   ;control port
;Pause 2 s before making measurements so the probe can stabilize on true readings.
;
02: Excitation with Delay (P22)
  1: 1      Ex Channel
  2: 0      Delay W/Ex (units = 0.01 sec)
  3: 500    Delay After Ex (units = 0.01 sec)
  4: 0      mV Excitation
;Measure the HMP155A temperature.
;
03: Volt (Diff) (P2)
  1: 1      Reps
  2: 5      2500 mV Slow Range    ;CR510, CR500 (250 0mv)
                                   ;CR23X (1000 mV) 21X, CR7 (5000 mV)
  3: 2      DIFF Channel         ;Yellow wire (2H), jumper (2L to 1L)
  4: 1      Loc [ T_C ]
  5: .14    Mult
  6: -80    Offset
;Measure the HMP155A relative humidity.
;
04: Volt (Diff) (P2)
  1: 1      Reps
  2: 5      2500 mV Slow Range    ;CR510, CR500 (2500mv); CR23X (1000 mV)
                                   ;21X, CR7 (5000 mV)
  3: 1      DIFF Channel         ;Blue wire (1H), white or purple wire (1L)
  4: 2      Loc [ RH_pct ]
  5: .1     Mult
  6: 0      Offset
;Turn the HMP155A off.
;
05: Do (P86)
  1: 51      Set Port 1 Low      ;Green wire (C1) if using SW12V device
                                   ;For CR23X or CR5000 use 59 for SW12V internal
                                   ;control port

```


Campbell Scientific Companies

Campbell Scientific, Inc.

815 West 1800 North
Logan, Utah 84321
UNITED STATES

www.campbellsci.com • info@campbellsci.com

Campbell Scientific Canada Corp.

14532 – 131 Avenue NW
Edmonton AB T5L 4X4
CANADA

www.campbellsci.ca • dataloggers@campbellsci.ca

Campbell Scientific Africa Pty. Ltd.

PO Box 2450
Somerset West 7129
SOUTH AFRICA

www.campbellsci.co.za • cleroux@csafrica.co.za

Campbell Scientific Centro Caribe S.A.

300 N Cementerio, Edificio Breller
Santo Domingo, Heredia 40305
COSTA RICA

www.campbellsci.cc • info@campbellsci.cc

Campbell Scientific Southeast Asia Co., Ltd.

877/22 Nirvana@Work, Rama 9 Road
Suan Luang Subdistrict, Suan Luang District
Bangkok 10250
THAILAND

www.campbellsci.asia • info@campbellsci.asia

Campbell Scientific Ltd.

Campbell Park
80 Hathern Road
Shepshed, Loughborough LE12 9GX
UNITED KINGDOM

www.campbellsci.co.uk • sales@campbellsci.co.uk

Campbell Scientific Australia Pty. Ltd.

PO Box 8108
Garbutt Post Shop QLD 4814
AUSTRALIA

www.campbellsci.com.au • info@campbellsci.com.au

Campbell Scientific Ltd.

3 Avenue de la Division Leclerc
92160 ANTONY
FRANCE

www.campbellsci.fr • info@campbellsci.fr

Campbell Scientific (Beijing) Co., Ltd.

8B16, Floor 8 Tower B, Hanwei Plaza
7 Guanghua Road
Chaoyang, Beijing 100004
P.R. CHINA

www.campbellsci.com • info@campbellsci.com.cn

Campbell Scientific Ltd.

Fahrenheitstraße 13
28359 Bremen
GERMANY

www.campbellsci.de • info@campbellsci.de

Campbell Scientific do Brasil Ltda.

Rua Apinagés, nbr. 2018 – Perdizes
CEP: 01258-00 – São Paulo – SP
BRASIL

www.campbellsci.com.br • vendas@campbellsci.com.br

Campbell Scientific Spain, S. L.

Avda. Pompeu Fabra 7-9, local 1
08024 Barcelona
SPAIN

www.campbellsci.es • info@campbellsci.es

Please visit www.campbellsci.com to obtain contact information for your local US or international representative.